

## Proflow™ II-E Mini-Cartridges

### Small-volume cartridge for ultrapure microelectronics fluids and gases

The Proflow™ II-E mini cartridge uses a PTFE membrane along with high-purity polypropylene supports that provide an economical alternative to all-fluoropolymer cartridges. It provides a high degree of retention and cleanliness along with good flow and lifetime. This filter is ideally suited for ultrapure microelectronics fluids and gases. The hydrophobic PTFE membrane serves as a highly efficient barrier to insure low moisture content of gases. Its design uses an internal 116 O-ring that is available in several materials.



### Benefits

- Good liquid and gas flow rates
- PTFE/ PP construction for chemical resistance
- Secure internal O-ring seal
- 100% integrity tested in cleanroom environment

### Applications

- Wet etch and clean
  - Dilute acids
  - DI water (<80°C)
- Ultrapure electronics-grade gases
- Drying systems

**Parker Hannifin Corporation** provides our customers with unsurpassed product consistency and cost-efficiency. Our experienced professionals can help you select the right solution for your application. For more information or to place an order, contact your local distributor. Information on product specifications, applications and chemical compatibility can be found on our web site at [www.parker.com](http://www.parker.com) or through your nearest **Parker Hannifin Corporation** office.

**Parker Hannifin Corporation** designs and manufactures an extensive line of innovative solutions for specific applications in the Microelectronics, Biopharmaceutical, Food and Beverage, Industrial and Chemical industries.



ENGINEERING **YOUR** SUCCESS.

# Proflow™ II-E Mini-Cartridges

## Specifications

### Materials of Construction

Membrane : PTFE  
 Support layers : Polypropylene  
 Structure : Polypropylene

All components are thermally bonded to ensure integrity and minimize extractables.

### Effective Filtration Area

3.1ft<sup>2</sup> (0.29m<sup>2</sup>) per D-size (125mm) cartridge

### Maximum Differential Pressure/ Temperature

Forward: 70psid (4.8bar) @ 75°F (24°C)  
 35psid (2.4bar) @ 140°F (60°C)  
 20psid (1.4bar) @ 167°F (75°C)  
 Reverse: 30psid (2.1bar) @ 75°F (24°C)


### Resistivity Rinse-up

The rinse-up volume required for Proflow-E® mini-cartridges to reach 18megohm-cm resistivity is approximately 12gal (45.4 liters).

## Performance Attributes


### Water Flow rates, Typical

0.03µm 0.20gpm/psid  
 0.05µm 0.40gpm/psid  
 0.45µm 2.6gpm/psid



## Ordering Information

Each cartridge is identified with a product number, pore size and lot number for traceability.



Specifications are subject to change without notification.  
 Polyflow is a registered trademark of Parker Hannifin Corporation.  
 Viton is registered trademark of E.I. DuPont de Nemours & Co., Inc.

© 2008 Parker Hannifin  
 Process Advanced Filtration Inc.  
 All Rights Reserved  
 SPEC -34E-MC Rev G 04/08



ENGINEERING YOUR SUCCESS.